

Six bee eye instructions

DmxSet Address	001 512	512 Address settings
Show Mode	Dmx Mode	Control platform mode
	Fast Mode	Quick run mode
	Slow Mode	Slow running mode
	Soud Mode	Voice-controlled operation mode
Sound Sense	0-99	Sound-control sensitivity adjustment
Pan Inverse	OFF	The X motor is positively rotating
	0 N	X motor reversal
tilt Inverse	OFF	Y motor is turning
	0 N	Y motor reversal
Default confirrm	YES	system reset
Fixture Rest	YES	system reset

16 Channel settings

channel	function	Say, Ming
1	0-255	The X motor is running
2	Horizontal operation is fine-tuning	0-255
3	0-255	The Y motor is running
4	Vertical operation is fine-tuning	0-255
5	0-255	XY motor speed
6	offset	Z motor running 0-127
	positive spin	128-191
	despin	192-255
7	Total dimming	0-255 Total dimming
8	R, tune, light	0-255 Red luminance adjustment
9	G aiming	0-255 Green luminance adjustment
10	B, tune, light	0-255 Blue luminance adjustment
11	W, tune, light	0-255 White brightness adjustment
12	Frequency, flash	0-255 Strobe adjustment is from slow to fast
13	0-10	Other channels are at work
	11-127	Color combination changes
	128-160	Color jump
	161-200	Color gradient 1

	201-255	Color gradient 2
14	speed adjustment	The 13th channel speed regulation function
15	reset	250-255
16	Laser channel	5-255